E+E

your partner
in sensor
technology.

User Manual EE610

Low Differential Pressure Sensor



Modbus

www.epluse.com

Content

1 General Information 4
1.1 Explanation of Warning Notices and Symbols 4
1.2 Safety Instructions 5
1.2.1 General Safety Instructions 5
1.2.2 Intended Use 5
1.2.3 Mounting, Start-up and Operation 5
1.3 Environmental Aspects 6
2 Scope of Supply 6
3 Product Description 7
3.1 General 7
3.1.1 Analogue Version 7
3.1.2 Digital Version 8
3.2 Dimensions 9
3.3 Electrical Connection 9
3.4 User Interface 10
3.4.1 LED Indication 10
3.4.2 Display 10
4 Mounting and Installation 11
4.1 General 11
4.2 Sensor Positioning and Pressure Connection 11
5 Setup and Configuration 13
5.1 Analogue Version 13
5.1.1 Select the Measuring Range with S1 and S2 14
5.1.2 Select the Response Time with S3 and S4 14
5.1.3 Select the Displayed Unit with S5 and S6 14
5.1.4 Select the Display Backlight with S7 14
5.1.5 Select the Output Signal with S8 14
5.1.6 Select the Source of Settings with S9 14
5.1.7 Select the Measuring Direction with S10 15
5.1.8 Outputs 15
5.2 Digital Version 15
5.2.1 BACnet Protocol Settings 16
5.2.2 Modbus RTU Protocol Settings 16
5.2.3 Modbus Register Map 17
5.2.4 Configurable Custom Modbus Map 18
5.2.5 Device Status Indication 18
5.2.6 Modbus RTU Example 19
5.3 Display Settings and Output Signals 20
5.3.1 Analogue Version with DIP Switch Settings 20
5.3.2 Analogue Version with PCS10 Settings or Digital Version 20
5.3.3 Customised Output Scaling 20
5.4 PCS10 Product Configuration Software 21
5.5 Product Configuration 21
5.5.1 EE610 Configuration using HA011070 21
5.5.2 EE610 Configuration using legacy USB configuration adapter HA011066 21

6 Maintenance and Service 22
6.1 Re-adjustment of the EE610 22
6.1.1 Zero Point Adjustment 22
6.1.2 Span Point Adjustment 23
6.1.3 Return to Factory Adjustment 23
6.1.4 Auto-zero (Optional) 23
6.2 Error Messages 24
6.3 Cleaning 24
6.4 Repairs 24
7 Technical Data 25
8 Conformity 27
8.1 Declarations of Conformity 27
8.2 Electromagnetic Compatibility 27
8.3 FCC Part 15 Compliance Statement 27
8.4 ICES-003 Compliance Statement 27

1 General Information

This user manual is intended to ensure proper handling and optimal functioning of the device. The user manual shall be read before commissioning the equipment and it shall be provided to all staff involved in transport, installation, operation, maintenance and repair. E+E Elektronik Ges.m.b.H. accepts no liability for any warranty or liability claims arising from this publication or improper handling of the product(s) described.

All information, technical data and diagrams included in this document are based on the information available at the time of writing. The document may contain technical inaccuracies and typographical errors. The contents will be revised on a regular basis and changes will be implemented in subsequent versions. The product(s) described and the contents of this document may be changed or improved at any time without prior notice.

All rights are reserved by E+E Elektronik Ges.m.b.H. No part of this document may be reproduced, published or publicly displayed in any form or by any means, nor may its contents be modified, translated, adapted, sold or disclosed to a third party without prior written permission of E+E Elektronik Ges.m.b.H.

PLEASE NOTE

Find this document and further product information on our website at www.epluse.com/ee610.

1.1 Explanation of Warning Notices and Symbols

Safety precautions

Precautionary statements warn of hazards in handling the device and provide information on their prevention. The safety instruction labeling is classified by hazard severity and is divided into the following groups:

DANGER

Danger indicates hazards for persons. If the safety instruction marked in this way is not followed, the hazard will verly likely result in severe injury or death.

WARNING

Warning indicates hazards for persons. If the safety instruction marked in this way is not followed, there is a risk of injury or death.

CAUTION

Caution indicates hazards for persons. If the safety instruction marked in this way is not followed, minor or moderate injuries may occur.

NOTICE

Notice signals danger to objects or data. If the notice is not observed, damage to property or data may occur.

Informative notes

Informative notes provide important information that is characterised by its relevance.

INFO

The information symbol indicates tips on handling the device or provides additional information on it. This information is useful to achieve optimum performance of the device.

The title field may deviate from “INFO” depending on the context. For instance, it may also read “PLEASE NOTE”.

1.2 Safety Instructions

1.2.1 General Safety Instructions

NOTICE

Improper handling of the device may result in its damage.

- Avoid any unnecessary mechanical stress and inappropriate use.
- Use the EE610 only as intended and observe all technical specifications.
- Installation, electrical connection, maintenance and commissioning shall be performed by qualified personnel only.
- Do not blow into the pressure connections.
- The device may be permanently damaged if a pressure is connected to the EE610 which is outside the measuring range according to the product specification.
- Do not apply the supply voltage to the output terminals.

1.2.2 Intended Use

The EE610 is dedicated for the highly accurate measurement of differential pressure. The multi-range device is suitable for air as well as all non-flammable and non-aggressive gases. The sensor can be used between -20 °C and +60 °C (-4 °F and +140 °F) and max. 95 %RH (non-condensing).

Please observe the mounting and installation instructions in chapter 4 Mounting and Installation. Check the measuring range for the appropriate use and be aware of the maximum overload limit.

⚠ WARNING

Non-compliance with the product documentation may cause safety risks for people and the entire measurement installation.

The manufacturer is not liable for any damage caused by improper handling, installation and maintenance of the device.

- Do not use the EE610 in explosive atmosphere or for measurement in aggressive gases.
- This device is not appropriate for safety, emergency stop or other critical applications where device malfunction or failure could cause injury to human beings.
- The device may not be manipulated with tools other than specifically described in this manual.

NOTICE

Failure to follow the instructions in this user manual may lead to measurement inaccuracy and device failures.

- The EE610 may only be operated under the conditions described in this user manual and within the specification included in chapter 7 Technical Data.
- Any unauthorized product modification leads to loss of all warranty claims. Modifications may only be carried out with express authorisation of E+E Elektronik Ges.m.b.H.!

1.2.3 Mounting, Start-up and Operation

The EE610 differential pressure sensor has been produced under state of the art manufacturing conditions, has been thoroughly tested and has left the factory after fulfilling all safety criteria. The manufacturer has taken all precautions to ensure safe operation of the device. The device shall be set up and installed in a way that does not impair its safe use. All applicable local and international safety guidelines for safe installation and operation of the device have to be observed. This user manual contains information and warnings that must be observed in order to ensure safe operation.

PLEASE NOTE

The manufacturer or his authorised agent can only be held liable in case of willful or gross negligence. In any case, the scope of liability is limited to the corresponding amount of the order issued to the manufacturer. The manufacturer assumes no liability for damage caused by non-compliance with the applicable regulations, operating instructions or the specified operating conditions. Any consequential damage is excluded from liability.

WARNING

Non-compliance with the product documentation may result in accidents, personal injury or property damage.

- Mounting, installation, commissioning, start-up, operation and maintenance of the device may only be carried out by qualified staff. Such staff must be authorised by the operator of the facility to carry out the mentioned activities.
- The qualified staff must have read and understood this user manual and must follow the instructions contained within. The manufacturer accepts no responsibility for non-compliance with instructions, recommendations and warnings.
- All process and electrical connections must be thoroughly checked by authorised staff before commissioning the device.
- Do not install or start-up a device suspected to be faulty. Mark it clearly as faulty and remove it from the process.
- Service operations other than described in this user manual may only be performed by the manufacturer. A faulty device may only be investigated and possibly repaired by qualified, trained and authorised staff. If the fault cannot be fixed, the device shall be removed from the process.

1.3 Environmental Aspects

PLEASE NOTE

Products from E+E Elektronik Ges.m.b.H. are developed and manufactured in compliance with all relevant environmental protection requirements. Please observe local regulations for the disposal of the device.



For disposal, the individual components of the device must be separated according to local recycling regulations. The electronics shall be disposed of correctly as electronics waste.

2 Scope of Supply

- EE610 Differential Pressure Sensor according to the ordering guide
- Quick Guide
- Test report according to DIN EN 10204-2.2
- Pressure connection set, including 2 m (6.6 ft) PVC hose with two ABS pressure connection nipples
- Mounting material
- For the digital version (ordering code J3): M16x1.5 cable gland for daisy chain wiring

3 Product Description

3.1 General


The EE610 offers ±0.5 Pa accuracy across the entire measuring range. The device has a maximum measuring range of ±100 Pa. With the analogue version, a measuring range of 25 %, 50 %, 75 % or 100 % of the maximum measuring range can be selected unidirectionally or bidirectionally. These settings can be made either via the PCS10 or via DIP switches. The pressure sensing element is piezoresistive and non-flow-through, and makes the sensor a long-term stable device.

The measured data is available on the analogue voltage and current output or on the RS485 interface with Modbus RTU or BACnet MS/TP protocol.

The setup can be performed with DIP switches on the electronics board (EE610 with analogue output) or with an optional adapter and the free PCS10 Product Configuration Software. The setup includes measuring range, output signal, response time, displayed units and backlight. The auto-zero interval can be set with the PCS10. A zero point and span adjustment can be performed with push buttons on the electronics board.

3.1.1 Analogue Version

Output (A7)




No.	Function
1	Pressure connection nipples
2	DIP switches for configuration (Measuring ranges, response time, ...)
3	Spring-loaded terminals
4	Push buttons for zero point and span point adjustment
5	Status LED
6	Cable gland for wiring
7	Service interface connector

Tab. 1 Design and components of the EE610 analogue sensor

3.1.2 Digital Version

Output (J3)




No.	Function
1	Pressure connection nipples
2	DIP switches for RS485 addressing
3	Screw terminals
4	Push buttons for zero point and span point adjustment
5	Status LED
6	Slide switch termination resistor
7	Service interface connector
8	Cable gland for wiring
9	Additional cable gland for daisy chain wiring

Tab. 2 Design and components of the EE610 digital sensor

3.2 Dimensions

Values in mm (inch)



Pressure fittings Ø5 (0.2)

\+ high pressure

\- low pressure

Pressure connection set is included in the scope of supply.

3.3 Electrical Connection

⚠ WARNING

Incorrect installation, wiring or power supply may cause overheating and result in personal injury or property damage.

Cables must not be under voltage during electrical installation and connection or disconnection, especially at terminal connections on circuit boards. For correct cabling, always observe the presented wiring diagram for the product version used.


The manufacturer cannot be held responsible for personal injury or damage to property caused by incorrect handling, installation, wiring, power supply or maintenance of the device.

The EE610 features screw terminals for connecting the power supply and the outputs. The cables are fed into the enclosure through the M16 cable gland.

NOTICE

It is important to ensure that the cable glands are closed tightly for the power supply and outputs cable. This is necessary to assure the IP rating of the enclosure according to EE610 specification, as well as for stress relief at the screw terminals on the EE610 board.

Analogue Version (A7)



Digital Version (J3)




Fig. 1 Connection Diagram

3.4 User Interface

3.4.1 LED Indication

Green LED	Description
Flashing (1 s interval)	The EE610 operates normally, the measured data is within the selected measuring range
One flash (2 s)	Confirms adjustment or return to factory settings
Off	No power supply or electronics failure
Fast flashing (0.2 s interval)	Auto-zero is executed, first time 10 s after start / reset

Red LED	Description
Flashing (1 s interval)	The measured data is out of the selected range (overload or reversed pressure connection)
One flash (2 s)	Indicates the failure of the attempt to adjust zero point or span point, or to return to factory adjustment

3.4.2 Display

The optional display shows the measured differential pressure and the selected unit (refer to chapter 5.1.3 Select the Displayed Unit with S5 and S6).

Additionally, the linear gauge indicates the actual pressure within the selected range (refer to chapter 5.1.1 Select the Measuring Range with S1 and S2).





Fig. 2 Examples for display indications

In case of differential pressure out of the measuring range or negative pressure due to inverse pressure connection the display indicates:



Δp < scale value low Δp > scale value high

Fig. 3 Out of range indications

4 Mounting and Installation

4.1 General

Use a matching wrench to fit the cable gland (in the scope of supply) onto the EE610 enclosure.

When using the EE610 with conduit connection, use a flat screwdriver to carefully knock open the blind at the top of the enclosure. Be careful not to damage the electronics inside the enclosure. The conduit adapter is not included in the scope of supply. The M16x1.5 cable gland opening shall be tightly closed using the blind plug supplied (refer to also chapter 3.2 Dimensions).

For best measurement results, please note the following:

- Mount the EE610 onto a vertical, smooth surface.
- The pressure connection nipples must point downwards.
- Avoid installation close to heaters and sources of strong electromagnetic interference.
- Insert the cable for supply voltage and output signal through the cable gland and connect it to the spring-loaded or srew terminals according to the wiring diagram (Fig. 1 Connection Diagram).
- Ensure that the connecting cable or wires do not impact with the push buttons in order to prevent unintentional trigger of the span or zero point adjustment.
- Close the cable gland tightly. This is essential for the compliance with the IP65 / NEMA 4X protection rating of the EE610 enclosure.

4.2 Sensor Positioning and Pressure Connection

To ensure a valid measurement, the sensor and the hose position must be selected correctly.

1. Mount the sensor on the correct place. Pay attention to the alignment (refer to Fig. 4).




Fig. 4 Mounting orientation

2. To connect the hoses at a duct use the pressure connection nipples (included in the scope of supply). Use a Ø7.5 mm (0.30”) drill for the holes regarding the dimensions in Fig. 5.




Fig. 5 Dimension of pressure connection nipples

3. Connect the pressure hose (included in the scope of supply) first to the EE610 and then to the duct. Route the pressure hose for avoiding sharp bends which might lead to the hose obstruction (Fig. 6 and Fig. 7).




Fig. 6 Pressure connection




Fig. 7 Pressure hose route

Depending on the application, the following connections are possible:




Fig. 8 Mounting examples

PLEASE NOTE

Make sure to connect the higher pressure at the “+” pressure connector and the lower pressure at the “-“ pressure connector. Inverted connection leads to “out of range” information on the optional display and at the analogue outputs, refer to chapter 5.2 Digital Version and 3.4.2 Display.

5 Setup and Configuration

The EE610 is ready to use and does not require any configuration by the user. The factory setup of the EE610 corresponds to the product order code. Please refer to the datasheet at www.epluse.com/ee610. If needed, the factory setup can be changed with the on-board DIP switches (analogue versions) or the PCS10 Product Configuration Software and the USB-C configuration stick (HA011070), please refer to the chapters below.

5.1 Analogue Version

Each EE610 sensor is delivered with the following factory settings (all switches on “0”):

Factory settings	
Measurement range	100 % of the full scale (±100 Pa)
Response time	50 ms
Displayed unit	Pa
Display backlight	On
Output signals	0 - 10 V and 4 - 20 mA
Source of settings	DIP switch settings

The analogue version is intended to be configured with the on-board DIP switches. All changes to the factory setup can also be done using the PCS10.

PLEASE NOTE

EE610 sensor versions with 8 DIP switches are not supported by the PCS10 Product Configuration Software.

Settings that can be changed via PCS10:

- Display visualisation (refer to chapter 5.3.2 Analogue Version with PCS10 Settings or Digital Version)
- Measurands and their measuring range
- Auto-zero on/off and interval (refer to chapter 6.1.4 Auto-zero (Optional))
- Response time

INFO

The EE610 is fully configurable. Before commissioning, set the individual configuration of the EE610 according to the application requirements using the DIP switches S1 to S10 as described below. The function of the DIP switches is also indicated inside the EE610 front cover.




Fig. 9 DIP switch examples

PLEASE NOTE

If settings have been changed via PCS10 and the DIP switch settings are to apply again, restore the factory settings before applying the DIP switches.

- Outputs scale: -100...+100 Pa
- Analogue bar limits:-100...+100 Pa
- Number of lines: 1
- Unit: Pa

5.1.1 Select the Measuring Range with S1 and S2

EE610-HV51A7

S1	S2	Pa	mbar	inch WC	mm H_2O
0	**0**	100	1	0.4	10.19
1	**0**	75	0.75	0.3	7.65
0	**1**	50	0.50	0.2	5.10
1	**1**	25	0.25	0.1	2.55

Tab. 3 DIP switch settings - Measuring range

5.1.2 Select the Response Time with S3 and S4

S3	S4	Response Time
0	**0**	50 ms
1	**0**	500 ms
0	**1**	2 s
1	**1**	4 s

Tab. 4 DIP switch settings - Response time

5.1.3 Select the Displayed Unit with S5 and S6

S5	S6	Displayed unit
0	**0**	Pa
1	**0**	mbar
0	**1**	inch WC
1	**1**	mm H_2O

Tab. 5 DIP switch settings - Displayed unit

5.1.4 Select the Display Backlight with S7

S7	Backlight
0	on
1	off

Tab. 6 DIP switch settings - Backlight

5.1.5 Select the Output Signal with S8

S8	Output signal
0	0 - 10 V and 4 - 20 mA
1	0 - 5 V and 0 - 20 mA

Tab. 7 DIP switch settings - Output signals

5.1.6 Select the Source of Settings with S9

(Versions with 10 DIP-Switches on the Electronics Board)

S9	Source of settings
0	DIP switches
1	PCS10

Tab. 8 Source for the settings

5.1.7 Select the Measuring Direction with S10

(Refer to the label on the inside of the cover for the functions)

S10	Measuring Direction
0	Bidirectional (±)
1	Unidirectional (up to the full scale value)

Tab. 9 DIP switch settings - Measuring Direction

PLEASE NOTE

Example of measuring ranges:

S1 = 0, S2 = 0, S9 = 0, S10 = 0 ±100 Pa or customised measuring range
S1 = 0, S2 = 1, S9 = 0, S10 = 1 0...50 Pa

5.1.8 Outputs

The measured data is available at the spring terminals as 0 - 10 V and 4 - 20 mA or as 0 - 5 V and 0 - 20 mA signals (refer to chapter 5.1.5 Select the Output Signal with S8). The EE610 provides a voltage and a current output signal at the spring terminals simultaneously.

A serious error is indicated by the analogue output jumping to the “Error indication” value set in the PCS10.

PLEASE NOTE

The factory default values for error indication are 10.5 V and 21 mA, respectively. The NAMUR indication is active ex works and can be changed via PCS10.

On a device equipped with a display, a serious error will also be indicated according to the error codes in Tab. 19 Displayed errors in chapter 6.2.

5.2 Digital Version

The RS485 digital interface version is intended to be configured with PCS10 Product Configuration Software and the USB-C configuration stick (HA011070). The device address can be overruled by setting the DIP switches. The factory setup of the EE610 corresponds to the specified order code.


Settings that can be changed with the PCS10

- Digital communication parameters
- Display visualisation (refer to chapter 5.3.2 Analogue Version with PCS10 Settings or Digital Version)
- Auto-zero on/off and interval (refer to chapter 6.1.4 Auto-zero (Optional))
- Response time

Hardware Bus Termination

For bus termination the EE610 features an internal 120 Ω resistor which can be activated using the slide switch on the electronics board (refer to Tab. 2 Design and components of the EE610 digital sensor).

Address setting via PCS10 Product Configuration Software




All DIP switches at position 0 → address has to be set via PCS10

Modbus (slave device): factory setting 44 (permitted values: 1…247).

BACnet (master device): factory setting 44 (permitted values: 0…127).

Example: Address is set via configuration software = factory setting.

Address setting via DIP switch



Modbus (slave device): Setting the DIP switches to any other address than 0, overrules the Modbus address set via PCS10 (permitted values: 1…247).

BACnet (master device): Setting the DIP switches to any other address than 0, overrules the BACnet address set via configuration software. BACnet Note: permitted values are 0…127. The 8th bit of the DIP switches is ignored (ID 127 = 0111 111). To set address 0 via DIP switches, the 8th bit shall be set to 1 (ID 0 = 1000 0000).

Example: Address set to 3 (= 0000 0011 binary).

5.2.1 BACnet Protocol Settings

	Factory settings	User selectable values (via PCS10)
Baud rate	As ordered via order code	9 600, 19 200, 38 400, 57 600, 76 800, 115 200
Data bits	8	8
Parity	None	None
Stop bits	1	1
BACnet address	44	0…127

Tab. 10 BACnet protocol settings

PLEASE NOTE

The recommended settings for multiple devices in a BACnet MS/TP network are 38 400, 8, none, 1.

BACnet address and baud rate can be set via:
- PCS10 Product Configuration Software and the USB-C configuration stick HA011070.
- BACnet protocol, refer to the PICS.

The EE610 PICS (Product Implementation Conformance Statement) is available on the E+E website at www.epluse.com/ee610.

5.2.2 Modbus RTU Protocol Settings

	Factory settings	Selectable values (via PCS10)
Baud rate	As ordered via order code	9 600, 19 200, 38 400, 57 600, 76 800, 115 200
Data bits	8	8
Parity	Even	None, odd, even
Stop bits	1	1, 2
Modbus address	44	1...247

Tab. 11 Modbus RTU protocol settings

PLEASE NOTE

- The recommended settings for multiple devices in a Modbus RTU network are 9600, 8, even, 1.
- The EE610 represents 1/2 unit load on an RS485 network.

The Modbus address, baud rate, parity and stop bits can be set via:

- PCS10 Product Configuration Software and the USB-C configuration stick HA011070.
  The PCS10 can be downloaded free of charge from www.epluse.com/pcs10.
- Modbus protocol in the register 1 (0x00) and 2 (0x01).
  Refer to Application Note Modbus AN0103 (available at www.epluse.com/ee610).

The measured values are saved as a 32 bit floating point value and as 16 bit signed integer, refer to chapter 5.2.3 Modbus Register Map.

The serial number as ASCII-code is located in read-only registers 1 - 8 (0x00 - 0x07).

The firmware version is located in read-only register 9 (0x08) (bit 15...8 = major release; bit 7...0 = minor release). The sensor name as ASCII-code is located in read-only registers 10 - 17 (0x09 - 0x11).

NOTICE

When reading information that spans multiple registers, it is always necessary to read all registers, even if the desired information requires less.

NOTICE

To obtain the correct floating point values, both registers have to be read within the same read cycle. The measured value may change between two Modbus requests. This can cause inconsistencies in the exponent and mantissa.

INFO

The Modbus function codes mentioned throughout this document shall be used as described in the MODBUS APPLICATION PROTOCOL SPECIFICATION V1.1b3, chapter 6:
www.modbus.org/docs/Modbus_Application_Protocol_V1_1b3.pdf

Communication settings (INT16)

Parameter	Register number[1] [Dec]	Register address[2] [Hex]	Size[3]
Write register: function code 0x06			
Modbus address[4]	1	00	1
Modbus protocol settings[4]	2	01	1
Initiate manual zeroing	508	1FB	1

Device information (INT16)

Parameter	Register number[1] [Dec]	Register address[2] [Hex]	Size[3]
Read register: function code 0x03 / 0x04			
Serial number (as ASCII)	1	00	8
Firmware version	9	08	1
Sensor name (as ASCII)	10	09	8
Device status (bit decoded)[5]	602	259	1

1) Register number (decimal) starts from 1.
2) Register address (hexadecimal) starts from 0.
3) Number of registers
4) For Modbus address and protocol settings refer to Application Note Modbus AN0103 (available at www.epluse.com/ee610).
5) Refer to chapter 5.2.5 Device Status Indication.

Tab. 12 EE610 registers for device setup

5.2.3 Modbus Register Map

The measurement data is saved as 32 bit floating point values (data type FLOAT32) and as 16 bit signed integer values (data type INT16).

FLOAT32

Parameter	Unit	Register number[1] [DEC]	Register address[2] [HEX]
Read register: function code 0x03 / 0x04			
Differential pressure	mm H_2O	1211	4BA
Differential pressure	mbar	1213	4BC
Differential pressure	Pa	1215	4BE
Differential pressure	kPa	1217	4C0
Differential pressure	inch WC	1219	4C2

INT16

Parameter	Unit	Scale[3]	Register number[1] [DEC]	Register address[2] [HEX]
Read register: function code 0x03 / 0x04				
Differential pressure	mm H_2O	10	4106	1009
Differential pressure	mbar	100	4107	100A
Differential pressure	Pa	1	4108	100B
Differential pressure	kPa	1000	4109	100C
Differential pressure	inch WC	100	4110	100D

1) Register number (decimal) starts from 1.
2) Register address (hexadecimal) starts from 0.
3) Examples: For scale 100, the reading of 2550 means a value of 25.5. For scale 50, the reading of 2550 means a value of 51.

Tab. 13 EE610 FLOAT32 and INT16 measured data registers

5.2.4 Configurable Custom Modbus Map

It is possible to map measured value/status registers arbitrarily in a block with up to 20 registers provided for this purpose. This means that registers of interest may be mapped in an area with consecutive registers, so that important values can be queried with a single command in one block.

The custom map can be configured via:

- PCS10 Product Configuration Software and the USB-C configuration stick HA011070.
  The PCS10 can be downloaded free of charge from www.epluse.com/pcs10.
- Modbus protocol commands, refer to the example in chapter 5.2.6 Modbus RTU Example.

The register block for the configuration of the customisable Modbus map consists of the registers 6001 (0x1770) to 6010 (0x1779). For the blockwise query of the measured values behind Modbus registers 3001 (0xBB8) to 3020 (0xBCB), the firmware accesses this configuration area and thus gets the information which measured value/status registers are to be output. A maximum of 10 user-defined registers can be mapped. The table below shows an example:

Registers ...		... with these assigned measurands ...			... map to registers ...		... mirrored from source registers	
Dec	Hex	Meas.	Unit	Type	Dec	Hex	Dec	Hex
Function code 0x10					*Function code 0x03/0x04*			
6001	1770	Δp	Pa	INT16	3001	BB8	4108	100B
6002	1771	V'	m^3/h	FLOAT32	3002	BB9	1055	41E
				FLOAT32	3003	BBA	1056	41F
6003	1772	v	m/s	FLOAT32	3004	BBB	1041	410
				FLOAT32	3005	BBC	1042	411

1) Register number starts from 1.
2) Protocol address starts from 0.

Tab. 14 Custom Modbus map example

5.2.5 Device Status Indication

If a critical error occurs, all Modbus values are set to NaN (according to IEEE754 for data type FLOAT32) or to 0x8000 (INT16). It is possible to read out all status and error information via Modbus register 609 (0x260). Errors are displayed in bit-coded form. If an event is present, the corresponding bit is set to 1.

Measured values outside the measuring range are limited with the corresponding limit value.

Error Bits	Description	Recommended action
Bit 0	Error: Sensor not adjusted	Carry out zero point adjustment
		Return to factory adjustment
		Return the unit to the E+E Customer Service
Bit 1	Error: Pressure measurement faulty	Check the installation and clean the device
		Carry out the zero point adjustment
		Return the unit to the E+E Customer Service
Bit 2	Error: Faulty display communication	Check the display connection
Bit 3	Error: Auto-zero did not work	Carry out zero point adjustment
		Return the unit to the E+E Customer Service

Tab. 15 Device status indication

5.2.6 Modbus RTU Example

The EE610's Modbus address is 44 [0x2C].

Please refer to

- MODBUS APPLICATION PROTOCOL SPECIFICATION V1.1b3, chapter 6: www.modbus.org/docs/Modbus_Application_Protocol_V1_1b3.pdf
- E+E Application Note Modbus AN0103 (available at www.epluse.com/ee610)

Read the differential pressure (FLOAT32) Δp = -32,260543 Pa from the register address 0x4BE:

Master (e.g. PLC) **EE610**

Request [Hex]:

Modbus address	Function code	Starting address Hi	Starting address Lo	Qty. of registers Hi	Qty. of registers Lo	CRC	
2C	04	04	BE	00	02	16	A2

Response [Hex]:

Modbus address	Function code	Byte count	Register 1 value Hi	Register 1 value Lo	Register 2 value Hi	Register 2 value Lo	CRC	
2C	04	04	0A	CC	C2	01	55	C1

Tab. 16 Example of a differential pressure query

NOTICE

To obtain the correct floating point values, both registers have to be read within the same read cycle. The measured value may change between two Modbus requests. This can cause inconsistencies in the exponent and mantissa.

Decoding of floating point values:

Floating point values are stored according to IEEE754. The byte pairs 1, 2 and 3, 4 are transformed as follows (numbers taken from Δp reading Modbus request/response example above):

Modbus response [Hex]

Byte 3	Byte 4	Byte 1	Byte 2
FB	A5	43	F8
MMMMMMMM	MMMMMMMM	SEEEEEEE	EMMMMMMM

Tab. 17 Modbus response

IEEE754

Byte 1	Byte 2	Byte 3	Byte 4
43	F8	FB	A5
0100 0011	1111 1000	1111 1011	1010 0101
SEEE EEEE	EMMM MMMM	MMMM MMMM	MMMM MMMM
Decimal value: 497.965972			

Tab. 18 Data representation according to IEEE754

5.3 Display Settings and Output Signals

5.3.1 Analogue Version with DIP Switch Settings

Refer to chapter 5.1 Analogue Version for the configuration options.

5.3.2 Analogue Version with PCS10 Settings or Digital Version

The factory setting of the display (if present) shows the measured differential pressure in Pascal [Pa]. All measurands can also be an selected as output signal. With the PCS10 Product Configuration Software and the optional USB-C configuration stick HA011070, the user can change the display layout, and the displayed unit (Pa, kPa, mbar, mm H_2O, inch WC).

Example of display visualisation




Fig. 10 One line with linear gauge

PLEASE NOTE

If settings were changed via PCS10 and DIP switch settings shall apply again, be sure to restore the factory settings before applying the DIP switches.

- Outputs scale: 100...100 Pa
- Analogue bar limits: -100...+100
- Number of lines: 1
- Unit: Pa

5.3.3 Customised Output Scaling

If the customised output scaling (SAL/SAH) was ordered ex works, the DIP switches S1/S2/S9/S10 may no longer be changed. In case of applied changes to the DIP switches the preset measuring ranges can no longer be ensured when resetting to S1/S2/S10 = 0.

Any changes will invalidate the measuring ranges indicated on the label.

PLEASE NOTE

If the settings have been changed via PCS10 or the DIP switches, restore the non-customised factory settings via PCS10 to the following:

- Outputs scale: ±100Pa
- Analogue linear gauge limits: ±100Pa
- Number of lines: 1
- Unit: Pa

5.4 PCS10 Product Configuration Software

PLEASE NOTE

EE610 versions with 10 DIP switches and digital versions of the EE610 are supported by the PCS10 Product Configuration Software.

The EE600 is ready to use and does not require any configuration by the user. The factory setup of the EE610 corresponds to the specified order code. Please refer to the datasheet at www.epluse.com/ee610. If needed, the user can change the factory setup with the help of the free PCS10 Product Configuration Software and the USB-C configuration stick (HA011070).

5.5 Product Configuration

5.5.1 EE610 Configuration using HA011070

For all types (analogue, digital)

NOTICE

The USB-C configuration stick HA011070 galvanically isolates the USB interface of the PC from the supply voltage of the EE610. When using the USB-C configuration stick the EE610 needs external supply.




Fig. 11 EE610 configuration using the HA011070 USB-C configuration stick

5.5.2 EE610 Configuration using legacy USB configuration adapter HA011066

(Not intended for new designs)

NOTICE

The EE610 may not be connected to any additional power supply when using the USB configuration adapter HA011066.




Fig. 12 EE610 connected to a PC running PCS10

To use the software for changes in settings, please proceed as follows:

1. Download the PCS10 Product Configuration Software from www.epluse.com/pcs10 and install it on the PC.
2. Connect the EE610 to the PC using the USB configuration adapter.
3. Start the PCS10 software.
4. Follow the instructions on the PCS10 opening page for scanning the ports and identifying the connected device.
5. Click on the desired setup mode from the main PCS10 menu on the left. Follow the online instructions of the PCS10 which are displayed when clicking the “Tutorial” button.
6. Changes are uploaded to the sensor by pressing the “Sync” button.

6 Maintenance and Service

The EE610 does not require any special maintenance, nevertheless it is recommended to perform a zero point adjustment every 12 month. If needed, the enclosure may be cleaned and the device may be re-adjusted as described below.

6.1 Re-adjustment of the EE610

A periodical re-adjustment of EE610 might be required by the regulations of certain industries or by the need of best long-term measurement accuracy. The zero point and the span point can be adjusted with push buttons on the EE610 electronics board.

For adjustment the device must be powered and the enclosure cover removed. Consequently, the adjustment may be performed by authorised staff only, observing the handling of electrical sensitive devices (ESD).

6.1.1 Zero Point Adjustment

The zero point adjustment is used to correct an eventual zero point deviation.

1. Remove the tubes from both pressure connections of the EE610. This ensures that the pressure is the same at both connections. If the sensor has an auto-zero setting, the tubes do not need to be removed.
2. Press the “zero point” button 1-2 seconds (refer to chapter 3 Product Description).
3. Successful zero point adjustment is confirmed by the green LED lighting up for 2 seconds.
4. If the red LED lights up for 2 seconds, this indicates that the zero point adjustment was not successful. In this case, please repeat step 2.

PLEASE NOTE

The zero point adjustment (step 2) may not be successful because the deviation is more than 5 % of the original full scale value of the device. This is 5 Pa for the 0...100 Pa range. If the zero point adjustment is not successful even after pressing the button for at least 10 seconds, the deviation is too high for zeroing. Please check the sensor, the tubes and the environment and make sure that the pressure connection nipples are free.

6.1.2 Span Point Adjustment

The span point adjustment is used to correct an eventual deviation of the span value.

PLEASE NOTE

Ensure to carry out a zero point adjustment as described above before setting the measuring range point.

1. Connect the differential pressure reference device / calibrator to the EE610 and set it according to the EE610 span value to be adjusted.
2. Note: The span value has to be set according to the selected measurement range.

Example:

Analogue version: (refer to chapter 5.1.2 Select the Response Time with S3 and S4, Tab. 3)
EE610-HV51A7, S1 = 1, S2 = 1, S10 = 0, span value = +25 Pa

Digital version: EE610-HV51J3, span value = +100 Pa

PLEASE NOTE

Observe the User Manual of the reference device.

3. Press the span point adjustment button (refer to chapter 3 Product Description).
4. Successful span point adjustment is confirmed by the green LED lighting up for 2 seconds.
5. If the red LED lights up for 2 seconds, this indicates that the span point adjustment was not successful. In this case, please repeat step 2.
6. Successful span point adjustment is confirmed by the green LED lighting up for 2 seconds.

PLEASE NOTE

The span point adjustment (step 2) may not be successful because the deviation is more than 5 % of the original full scale value of the device.
This is 5 Pa for the 0...100 Pa range. In this case, the set point adjustment can be forced by pressing and holding the span point button for 10 seconds. If the zero point adjustment is not successful even after pressing the key for at least 10 seconds, then the deviation is too high for zeroing. Please check the sensor, the tubes and the environment and make sure that the pressure connection nipples are free.

6.1.3 Return to Factory Adjustment

1. Press and hold simultaneously both “zero” and “span” buttons for 5 seconds.
2. The successful return to the factory setting is confirmed by the green LED lighting up for 2 seconds.
3. If the red LED lights up for 2 seconds, this indicates that the factory reset was not successful. In this case, repeat step 2.

PLEASE NOTE

The return to the factory adjustment affects both the zero point and the span point adjustment.

6.1.4 Auto-zero (Optional)

With auto-zero, no maintenance of the sensor is required. Auto-zero is carried out every 24 hours (factory setting). The interval can be set from 10 minutes up to 7 days and can be changed by using the PCS 10 and the USB configuration adapter (refer to chapter 5.4 PCS10 Product Configuration Software). The interval can be set from 10 minutes up to 7 days. For this purpose DIP switch 9 (refer to chapter 5.1.6 Select the Source of Settings with S9) has to be in position 1 (ON). During the auto-zero procedure (takes approx. 4 s), the green LED flashes quickly (refer to chapter 3.4.1 LED Indication) and the output signal value is frozen.

PLEASE NOTE

If the auto-zero interval was changed via PCS10 and DIP switch settings are applied again, the auto-zero interval value will be adopted.

6.2 Error Messages

Following error messages can be read on the display.

Code	Description	Recommended action
13	Sensor not adjusted	Carry out zero point adjustment
		Return to factory adjustment
		Return the unit to the E+E Customer Service
14	Pressure measurement faulty	Check the installation and clean the device
		Carry out the zero point adjustment
		Return the unit to the E+E Customer Service
18	Auto-zero did not work	Carry out zero point adjustment
		Return the unit to the E+E Customer Service
21	Faulty display communication	Check the display connection

Tab. 19 Displayed errors

6.3 Cleaning

Use a damp soft cloth to remove deposits of dust or dirt from the exterior of the device and from the display. Do not attempt to clean the interior of the device. Do not use any solvents, alcohol or abrasive cleaning agents.

6.4 Repairs

Repairs may be carried out by the manufacturer only. The attempt of unauthorized repair excludes any warranty claims.

7 Technical Data

Measurands

Differential Pressure (Δp)

Measurement principle		Piezoresistive, no flow-through
Measuring range		±100 Pa
Analogue scaling	**Analogue output**	±25 / ±50 / ±75 / ±100 Pa field selectable with DIP switches[1)] 0...25 / 50 / 75 / 100 Pa field selectable with DIP switches[1)]
	With PCS10	Configurable within max. measuring range
Accuracy, typ. @ 20 °C (68 °F), incl. hysteresis, non-linearity and repeatability		±0.5 Pa = ±0.5 % FS FS = full scale (100 Pa)
Temperature dependency, typ.		0.03 Pa/K
Response time t_{90}	**Analogue output[1)]**	50 ms / 500 ms / 2 s / 4 s selectable with DIP switches Configurable in the range from 0.05 to 30 s with the PCS10
	Digital interface[2)]	Configurable in the range from 0.5 to 30 s with the PCS10
Auto-zero interval		24 h (factory setting) Configurable between 10 min and 7 days with PCS10. Can be deactivated.
Long-term stability		<0.5 Pa/year
Overload limits		±7 000 Pa

1) Factory setup analogue output: measurement range ±100 Pa; response time t_{90}: 50 ms; displayed unit: Pa; display backlight: on; analogue outputs: 0 - 10 V and 4 - 20 mA. Other ranges upon request.
2) Factory setup RS485: response time t_{90}: 500 ms; Displayed unit: Pa; Display backlight: on.

Outputs

Analogue

Analogue output[1)]	0 - 5 V or 0 - 10 V and 0 - 20 mA or 4 - 20 mA (3-wire)	-1 mA < I_L < 1 mA R_L ≤ 500 Ω	I_L = load current R_L = load resistor

1) Voltage and current output signals available simultaneously at the spring loaded terminals. Settings selectable with DIP switches. Factory setup analogue output: measurement range 0...100 % FS; response time t_{90}: 50 ms; displayed unit: Pa; display backlight: on; analogue outputs: 0 - 10 V and 4 - 20 mA. Other ranges upon request.

Digital

Digital interface[1)]	RS485 (EE610 = 1/2 unit load)
Protocol **Factory settings** **Supported Baud rates** **Measured data types**	Modbus RTU Baud rate see order information, parity even, 1 stop bit, Modbus address 44 9 600, 19 200 and 38 400 FLOAT32 and INT16

1) Factory setting RS485: Response time t_{90}: 500 ms; Displayed units: Pa; Display backlight: on.

General

Power supply class III USA & Canada: Class 2 supply necessary, max. voltage 30 V DC	15 - 35 V DC or 24 V AC ±20 %		
Current consumption, typ. @ 0 Pa (0 psi) / 24 V DC		**Analogue output**	**Digital interface**
	Without display	23 mA	8 mA
	Display with backlight	49 mA	29 mA
Electrical connection **Analogue output** **Digital interface**	Spring-loaded terminals, max. 1.5 mm^2 (AWG16) Screw terminals, max. 2.5 mm^2 (AWG14)		
Cable gland	M16x1.5		
Display	Graphic, with backlight		
Selectable units on display with **Analogue output via DIP switch** **Analogue output and digital interface via PCS10**	Pa, mbar, inch WC, mm H_2O Pa, kPa, mbar, inch WC, mm H_2O		
Humidity range	0...95 %RH, non-condensing		
Temperature range **Operation** **Storage**	-20...+60 °C (-4...+140 °F) -40...+70 °C (-40...+158 °F)		
Enclosure **Material** **Protection rating**	PC (Polycarbonate) UL94 V-0 (with display UL94 HB) approved IP65 / NEMA 4X		
Electromagnetic compatibility	EN 61326-1 Industrial environment FCC Part15 Class A ICES-003 Class A		
Shock and vibration	Tested according to EN 60068-2-64 and EN 60068-2-27		
Conformity	CE UKCA		

Configurability

All devices, analogue and digital, with or without auto-zero, can be configured via DIP switch or via PCS10. Configuration options see above.

8 Conformity

8.1 Declarations of Conformity

E+E Elektronik Ges.m.b.H. hereby declares that the product complies with the respective regulations listed below:

CE European directives and standards.

and

UKCA UK statutory instruments and designated standards.

Please refer to the product page at www.epluse.com/ee610 for the Declarations of Conformity.

8.2 Electromagnetic Compatibility

EMC for industrial environment.
The sensor is a group 1 devices and correspond to class A.

⚠ WARNING

This device is not intended for use in residential areas and cannot ensure adequate protection of radio reception in such environments.

8.3 FCC Part 15 Compliance Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

8.4 ICES-003 Compliance Statement

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Company Headquarters &
Production Site

E+E Elektronik Ges.m.b.H.
Langwiesen 7
4209 Engerwitzdorf | Austria
T +43 7235 605-0
F +43 7235 605-8
info@epluse.com
www.epluse.com

Subsidiaries

E+E Sensor Technology (Shanghai) Co., Ltd.
T +86 21 6117 6129
info@epluse.cn

E+E Elektronik France SARL
T +33 4 74 72 35 82
info.fr@epluse.com

E+E Elektronik Deutschland GmbH
T +49 6171 69411-0
info.de@epluse.com

E+E Elektronik India Private Limited
T +91 990 440 5400
info.in@epluse.com

E+E Elektronik Italia S.r.l.
T +39 02 2707 86 36
info.it@epluse.com

E+E Elektronik Korea Ltd.
T +82 31 732 6050
info.kr@epluse.com

E+E Elektronik Corporation
T +1 847 490 0520
info.us@epluse.com

your partner
in sensor
technology.

BA_EE610 | Version v1.6 | 04-2025
© Copyright E+E Elektronik Ges.m.b.H. | All rights reserved.

www.epluse.com